




# Code setting guide for the Dogtra 640C TD



1. Start with the receiver/collar turned off and the transmitter turned on. Select the intensity level 0 with the intensity selection dial.



2. Place the red dot on the back of the transmitter against the red dot on the receiver/collar. Hold the two red dots together for 5 seconds, until the green LED on the receiver/collar starts to blink rapidly, and then separate the two red dots.



3. Hold the Nick & Continuous Nick Button and Boosted Constant Button of the transmitter on the left side of the transmitter simultaneously down for 3 seconds or until the rapid green blink of the LED on the receiver/collar resumes a slower pace. The code setting work is now completed. If you push the Pager button of the transmitter, the receiver/collar will vibrate.