



**Dogtra-Europe**  
12 – 14 Rue Augustin Fresnel  
78310 Coignieres, FRANCE  
TEL: +33 (0) 130 62 65 65  
FAX: +33 (0) 130 62 66 11  
E-mail: info@dogtra-europe.com

### **Code setting guide for Dogtra 4500 EDGE / 4502 EDGE / 4503 EDGE / 4504 EDGE**



MODE Selection Dial on top of the transmitter

1. Start with the receiver/collar turned off and the transmitter turned on. Select the "C" position with the Mode Selection Dial on top of the transmitter.



Intensity Selection Dial on top of the transmitter

2. Select the intensity level 0 with the intensity selection dial.



ON/OFF button on the receiver/collar

3. Hold down the On/Off button on the receiver/collar for several seconds, until the green LED on the receiver/collar starts to blink rapidly, and then release the button.



4. Hold the transmitter button corresponding to the desired receiver/collar \* down for 3 seconds or until the rapid green blink of the LED on the receiver/collar resumes a slower pace. The code setting work is now completed.

\* Example: Hold down the BLUE transmitter button to code it with the BLUE receiver/collar.