



Dogtra-Europe
12 – 14 Rue Augustin Fresnel
78310 Coignieres, FRANCE
TEL: +33 (0) 130 62 65 65
FAX: +33 (0) 130 62 66 11
E-mail: info@dogtra-europe.com

Code setting guide for Dogtra 612 C

Synchronization of the transmitter with the BLACK receiver/collar

- 1) Start with the receiver/collar turned off. Put the intensity dial on the transmitter to “0”.
- 2) Place the red dot on the back of the transmitter to the red dot of the receiver/collar you would like to code. Hold the two red dots together for 5 seconds until the green LED blinks rapidly on the receiver/collar, then separate the red dots.
- 3) While the green LED is rapidly blinking on the receiver/collar, press the 2 grey buttons on the front and side of the transmitter simultaneously. The LED indicator light on the receiver/collar will blink every 4 seconds when the coding is complete.
- 4) Press the grey button on the front of the transmitter. If the receiver/collar vibrates, the synchronization has been successful.

Synchronization of the transmitter with the ORANGE receiver/collar

- 1) Turn the transmitter on by pushing the ON/OFF button located on the side of the transmitter and set the intensity dial to “0”.
- 2) Place the red dot on the back of the transmitter to the red dot of the receiver/collar you would like to code. Hold the two red dots together for about 5 seconds until the green LED blinks rapidly on the receiver/collar.
- 3) While the green LED is rapidly blinking on the receiver/collar, press the 2 orange buttons on the front and side of the transmitter simultaneously. The LED indicator light on the receiver/collar will blink every 4 seconds when the coding is complete.
- 4) Press the orange button on the front of the transmitter. If the receiver/collar vibrates, the synchronization has been successful.

Please feel free to call us at +33 (0) 130 62 65 65 if you have any difficulties.