



**Dogtra-Europe**  
12 – 14 Rue Augustin Fresnel  
78310 Coignieres, FRANCE  
TEL: +33 (0) 130 62 65 65  
FAX: +33 (0) 130 62 66 11  
E-mail: info@dogtra-europe.com

## **Code setting guide for Dogtra ARC 1202S**

### **Synchronization of the transmitter with the BLACK receiver/collar**

1. Start with the receiver/collar turned off. Turn on the transmitter by pushing the ON/OFF button located on the side of the transmitter. Set the intensity dial to "0".
2. Hold the On/Off button of the receiver/collar down for about 5 seconds until the green LED blinks rapidly on the receiver/collar.
3. While the green LED is rapidly blinking on the receiver/collar, press the 2 grey buttons on the front and side of the transmitter simultaneously for 2 or 3 seconds. The LED indicator light on the receiver/collar will blink every 4 seconds when the coding is complete.
4. Press the grey button on the front of the transmitter. The receiver/collar should vibrate, indicating that the synchronization process has been successfully completed.

### **Synchronization of the transmitter with the ORANGE receiver/collar**

1. Start with the receiver/collar turned off. Turn on transmitter on by pushing the ON/OFF button located on the side of the transmitter and set the intensity dial to "0".
2. Hold the On/Off button of the receiver/collar down for about 5 seconds until the green LED blinks rapidly on the receiver/collar.
3. While the green LED is rapidly blinking on the receiver/collar, press the 2 orange buttons on the front and side of the transmitter simultaneously for 2 or 3 seconds. The LED indicator light on the receiver/collar will blink every 4 seconds when the coding is complete.
4. Press the orange button on the front of the transmitter. The receiver/collar should vibrate, indicating that the synchronization process has been successfully completed.

Feel free to call us at +33 (0) 130 62 65 65 if you have any difficulties.