




Dogtra-Europe


12 – 14 Rue Augustin Fresnel
78310 Coignieres, FRANCE
TEL: +33 (0) 130 62 65 65
FAX: +33 (0) 130 62 66 11
E-mail: info@dogtra-europe.com

Code setting guide for Dogtra ARC 800 CAMO



Intensity selection dial of the transmitter

1. Start with the receiver/collar turned off and the transmitter turned on. Select the intensity level **0** with the intensity selection dial.



2. Place the red dot on the back of the transmitter against the red dot on the receiver/collar. Hold the two red dots together for five seconds, until the green LED on the receiver/collar starts to blink rapidly, and then separate the two red dots.



Nick and Constant Button of the transmitter

3. Hold the Nick button and the Constant button on the left side of the transmitter simultaneously down for 3 seconds or until the rapid green blink of the LED on the receiver/collar resumes a slower pace.
The code setting work is now completed. If you push the Pager button of the transmitter, the receiver/collar will vibrate.